STATIC ANALYSIS OF A SIMPLY SUPPORTED BEAM



Figure 1

All dimensions are in *mm*

Objective: To find the deflection, stress, strain, shear force and bending moment diagram of simply supported beam with concentrated load as shown in **Figure 1**.

Analysis Type : Static

Modulus of elasticity, *E* *=207 GPa*

Poisson's ratio, *v* *= 0.3*

PROCEDURE

STEP

1. Create three points at (0, 0, 0) (800, 0, 0) and (1600, 0,0)

Commands : POINT, ADD

Menu : Geometry → Key point → Create → By X/Y/Z

Parameters : (To be filled by the user)

Coordinate Data	0/0/0
Coordinate Type	0
Entity ID	

Similarly create points (800/0/0) and (1600/0/0)

Note:

Click "***Apply***" button or press ***cntrl+enter*** key after completing each step. "Done" message appears on message box for every step executed successfully.

At the end of the above operation/s, your screen should look like this.



2. Create a line

Commands : CURVE, LINE

Menu : Geometry → Curve → Create →Line

Parameters :

End points	Use Mouse to pick the end points;P1/P2
Entity ID	1

Similarly create curve using points P2 and P3.

At the end of the above operation/s, your screen should look like this.



3. Meshing using beam elements

Commands : FEM, BAR

Menu : Mesh → FE Mesh → Bar

Parameters :

Curve	1/2
Element Size	0.1
Type	2-node
Subdivisions	10
Bias	1.0

Note:

Right click/left click mouse point to alter sub-divisions.

At the end of the above operation/s, your screen should look like this.



4. Merge duplicate nodes

Commands : NODE,MERGE

Menu : Mesh →Node → Modify → Merge

Parameters :



Duplicate nodes being merged will be highlighted.

5. Erase curve

Commands : CURVE,ERASE

Menu : Geometry →Curve → Miscellaneous → Erase

Parameters :



Note:

Likewise erase key points by POINT,ERASE,ALL command.

6. Specify displacement boundary conditions

Commands : BC,ADD

Menu : Load/BC → Displacement BC → Add

Parameters :

Node IDs	Select the end nodes ;1/22
BC Value	1/0/2/0/3/0
LCS ID	0



At the end of the above operation/s, your screen should look like this.



7. Specify material properties

Command : MATERIAL, ISO

Menu : Property → Material → Isotropic → Add

Parameters :

Element IDs	All
Material Data	207000/0.3/0/0/0
Material ID	1



8. Specify Beam Properties

Command : BEAMSECTION, ADD

Menu : Property → Physical → Beam Properties →Standard Section →Add

Parameters :

Element IDs	All
Cross section Shape	RECT/25/100
Angle about axis	0
Node offsets (yoff/zoff)	0/0



At the end of the above operation/s, your screen should look like this.



9. Specify point load

Command : FORCE, ADD

Menu : Load/BC → Point Load → Add

Parameters :

Node IDs	11
Data	15000
Component	Fy
LCS ID	0
Set ID	1

At the end of the above operation/s, your screen should look like this.



10. Set the analysis type

Command : ANTYPE, SET

Menu : Analysis → Analysis Type

Parameters :

Analysis Type	Static

11. Set the analysis options

Command : ANOPTION, SET

Menu : Analysis → Analysis Options

Parameters :

Linear Solver	Multi Frontal

12. Save the project model

Menu : File → Save

13. Submit the job into FEAST

Menu : Analysis →Run solver



Note:

"Finished successfully" message appears on message box after executing is completed.

14. Perform post processing

i) Deformed shape

Command : POST, DISPDEFORM

Menu : Post → Deformed shape

Parameters :

Scale factor	1

At the end of the above operation/s, your screen should look like this.



ii) Stress contour

Command : POST, BEAMCONTOUR

Menu : Post → Beam Plots → Stress Contour

Parameters :

Component	BENDING-XY
Decimal Places	2
No. of contours	9
Element List	All

At the end of the above operation/s, your screen should look like this.



iii) Strain contour

Command : POST, BEAMSTRAINCONTOUR

Menu : Post → Beam Plots → Strain Contour

Parameters :

Component	BENDING-XY
Decimal Places	2
No. of contours	9
Element List	All

At the end of the above operation/s, your screen should look like this.



iv) Beam force

a. Shear force diagram

Command : POST, BEAMFORCE

Menu : Post → Beam Plots → Force Diagram

Parameters :

Component	SHEAR 1
Plane	Plane-1
Decimal Places	2
Scale Factor	1
No. of contours	9

At the end of the above operation/s, your screen should look like this.



b. Bending moment diagram

Command : POST, BEAMFORCE

Menu : Post → Beam Plots → Force Diagram

Parameters :

Component	BM2
Plane	Plane-1
Decimal Places	2
Scale Factor	1
No. of contours	9

At the end of the above operation/s, your screen should look like this.



c. *.DAT file shows the input data and *.OUT file shows the output file.

Hint: $Deflection, \delta = \frac{PL^3}{48EI}$